HE922 Dual Sync Controller Installation & Wiring



Number	colour	colour	function	A	B
1	Yellow		Motor -	MA-	MB-
2	red		Hall affect 5V	5V	5V
3	white		Hall effect 1	h1a	h1b
4	black		Hall effect 0V	(-)ve	(-)ve
5	green		Motor +	MA+	MB+
6	blue		Hall effect 2	N/C	N/C